



CHARACTERISTICS

- Cleaner
- Removes fresh, non-cured, polyurethane foam/adhesive, wax, grease, oil etc.

APPLICATIONS

- For internal cleaning of the NBS Foam gun
- Removal of fresh PU-foam or polyurethane adhesive on the NBS gun and surfaces

TECHNICAL CHARACTERISTICS

Shelf life, in the original packing in a cool and dry area, vertically	12 months
--	-----------

PACKING AND COLOURS

12 cans of 500 ml/box - 70 boxes/pallet

METHOD OF USE

Cleaning of the foam gun

- Screw the **Parafoam Gun and Spray Cleaner** on the adapter after removal of the empty PU-foam can.
- Pull the trigger a few times until clear cleaning fluid comes out.
- The cleaner should remain in the gun for approx. 2 minutes.
- Pull the trigger again to refill the gun with cleaner.
- Unscrew the **Parafoam Gun and Spray Cleaner** can.
- Clean and dry the screw thread and spray the adapter with **Vaseline Spray**.
- Screw a new can of **Parafoam NBS** (gun foam) on the gun immediately. Pull the trigger a few times until foam is released and the **Parafoam Gun and Spray Cleaner** is completely removed. The gun now is ready for use again.

Removal of fresh PU foam

- Put the spray nozzle on the NBS valve.
- Point the can into the right direction.
- Press spray nozzle with finger.
- Remove the spray nozzle after use.

SAFETY

Safety data sheet available on request.

LIMITATIONS

The cleaner contains acetone and can affect coatings, paints and textiles.

This technical data sheet replaces all previous editions. The data on this sheet have been compiled according to the last laboratory report. Technical characteristics can be changed or adapted. We are not responsible for any incomplete information. Before use, one needs to ensure that the product is suitable for his application. Therefore, tests are necessary. Our general conditions apply.